



Irrigation Depot™

Comment relier un tuyau 1/4"
à un tuyau principal de 1/2 ou 3/4"



Installation

0-42315



Irrigation Depot™